



**American
Autowire**

www.americanautowire.com 856-933-0801

1. Plug the 510120 power top harness into the motor connection and the switch connection.
2. Plug the bare terminal end of 510120 harness into accessory connector #51/52 on the main dash harness maintaining color continuity with red wire in that location.
3. Clip off the first section of the enclosed 30 amp circuit breaker, remove the 30 amp fuse from "BAT2" location on the fusebox, and replace it with the 30 amp circuit breaker.

**POWER TOP KIT,
1968-72 Chevelle,
Classic Update Series**

510120

92969187 instruction rev 1.0 5/8/2013



**American
Autowire**

www.americanautowire.com 856-933-0801

1. Plug the 510120 power top harness into the motor connection and the switch connection.
2. Plug the bare terminal end of 510120 harness into accessory connector #51/52 on the main dash harness maintaining color continuity with red wire in that location.
3. Clip off the first section of the enclosed 30 amp circuit breaker, remove the 30 amp fuse from "BAT2" location on the fusebox, and replace it with the 30 amp circuit breaker.

**POWER TOP KIT,
1968-72 Chevelle,
Classic Update Series**

510120

92969187 instruction rev 1.0 5/8/2013