



existing wires from rear
body kit 500484

INSTALLATION:

Use this Cameo accessory kit to connect your tail lamps, back-up lamps, and license plate lamps. Using the supplied connectors, terminals, grommets, and boot assemblies, connect this kit to your 500484 rear body wires. Install all components as shown in the diagram above.

another wiring product by...



**American
Autowire**

We Make Wiring Easy!!

150 Heller Pl #17 W Bellmawr, NJ 08031 856-933-9301

PART #

500485

DESCRIPTION:

REAR BODY ACCESSORY KIT

Cameo

92965284 instruction sheet

Rev 0.0 9/3/2002