



For Manual Transmission cars.

1. Plug this console rear lamp extension into the mating connector at location 17 on page 3 on your dash harness (510107 for 1970-72 or 510160 for 1968-69) instructions.

For Automatic Transmission cars.

1. Plug the Automatic Transmission Console Shifter Light Harness into the open cavity on the Console Rear Courtesy Lamp Harness Extension.
2. Ground the ring terminals to the floor of the car in the stock location.
3. Plug the completed assembly into the mating connector at location 17 on page 3 on your dash harness (510107 for 1970-72 or 510160 for 1968-69) instructions.



**American
Autowire**

American Autowire
800-482-9473

