

In this kit you will find the following:

1. 4 cushioned clamps.
2. 2 rubber grommets.
3. Misc. connectors and terminals to complete engine, alternator, and forward lamp connections.

The clamps will be used to securely route the engine harness wires up across the back of the firewall in the engine bay behind the engine. You may use your original bolts that secured the original clamps to attach the new clamps. The two grommets will be used to line the stock engine and forward lamp harness connection holes at the firewall prior to routing the new harness out into the engine compartment. The various terminals and connectors will be used to complete the several connections under the hood of the truck. Those detailed instructions can be found on pages 9 and 10 of the main instruction set (510261).



**American
Autowire**

www.americanautowire.com 856-933-0801

PART #

510265

DESCRIPTION:

**Clamp, Grommet, and Parts Kit
1961 - 66 Ford Truck
Classic Update Series**

92969842 instruction sheet rev 0.0 8/18/2011