



American Autowire

www.americanautowire.com 856-933-0801

NOTE: This harness routes through the inside of your trunk lid just as your original one did. The orange wire is a 12 volt fused battery feed that should be used as a trunk lamp or LED memory feed. The light green wires are your back up lamps. The yellow and brown (LH) wires and dark green and brown (RH) wires are your stop - turn, and tail lamps. The 4 position connector with lt. green, brown, yellow, and dk. green wires and the single position connector with the orange wire will plug into the rear body harness 510365 at the trunk hinge area. Detailed instructions on making this connection can be found in the 510365 instruction set.

1965 Impala
Classic Update Kit
Trunk Lid Harness

bag
P

510367

92970302 instruction rev 0.0 2/25/2013



American Autowire

www.americanautowire.com 856-933-0801

NOTE: This harness routes through the inside of your trunk lid just as your original one did. The orange wire is a 12 volt fused battery feed that should be used as a trunk lamp or LED memory feed. The light green wires are your back up lamps. The yellow and brown (LH) wires and dark green and brown (RH) wires are your stop - turn, and tail lamps. The 4 position connector with lt. green, brown, yellow, and dk. green wires and the single position connector with the orange wire will plug into the rear body harness 510365 at the trunk hinge area. Detailed instructions on making this connection can be found in the 510365 instruction set.

1965 Impala
Classic Update Kit
Trunk Lid Harness

bag
P

510367

92970302 instruction rev 0.0 2/25/2013