


Classic Update Series

1978-80 Camaro

START HERE !

PLEASE READ THIS BEFORE STARTING INSTALLATION !

This wiring kit is designed for ease of installation. Please read the guidelines below, BEFORE STARTING your installation to guarantee a successful job. Use an appropriate crimping tool which folds the wings of the open barrel terminals down into the wire as shown below. ALL TERMINALS THAT YOU INSTALL SHOULD BE PROPERLY SOLDERED. Our factory crimped terminations are installed by GM approved five ton presses, and soldering these terminations is not necessary. AAW offers a great terminal crimping video entitled "Proper Crimping Video". It can be viewed by visiting YouTube. Type the following address into your web browser to go directly to the video: www.youtube.com/watch?v=8u_EkMsioMy.



AS THIS HARNESS IS DESIGNED FOR USE IN A MODIFIED CAR REQUIRING A HIGHER RATE OF CHARGE WITH AN INTERNALLY REGULATED "SI" OR SINGLE WIRE STYLE ALTERNATOR. IT CAN ALSO BE USED WITH THE LATER "CS" AND "CS-D" UNITS BY USING ALTERNATOR ADAPTERS WHICH ARE SOLD SEPARATELY. CONTACT AAW OR YOUR FAVORITE DEALER FOR THE PROPER ALTERNATOR ADAPTER FOR YOUR CAR.

STEP 1: DISCONNECT YOUR BATTERY:

Disconnect the battery before installing the wiring kit to prevent any accidental shorting caused by loose bare wire ends.

STEP 2: START INSTALLING KIT:

This kit is broken down into individual steps that are identified by a letter printed on the instruction sheets visible through each bag. These letters are the order of operation for installing your kit. Start with bag letter G, then H, etc. The order of installation is shown below.

G 510568 Dash Harness Kit
H 510569 Instrument Cluster Kit
J 510570 Engine Kit
L 510571 Front Light Kit
M 510582 Rear Body Kit
N 500708 Courtesy Light Kit

STEP 3: RECONNECT YOUR BATTERY:

When you have completed the installation and are ready to reconnect the battery, make sure that the following electrical system grounds are in place:

A. Battery is grounded to the ENGINE BLOCK.
B. Battery is grounded to the frame.
C. Engine block is grounded to the frame.
D. Body is grounded to the frame.

STEP 4: CHECK ALL ELECTRICAL FUNCTIONS:

Any non-functioning items should be checked for proper installation. Any problems with your wiring and electrical circuit functions should be addressed to American Autowire Systems, Inc. as soon as possible to avoid any warranty problems.

If you have any questions concerning this or any of our products, please feel free to call us at 1-800-482-WIRE.

AMERICAN AUTOWIRE MAKES IT EASY !!

page 1

We carry many accessories for your 1978-80 Camaro

p/n R0067108
OEM style non-stick harness tape



p/n 01997983 (1977-81)
OEM style turn signal switch



p/n 01242101 (1974-77)
pedal mounted T400 kickdown switch
(if modifying your car with a T400)



p/n 03943657 (1969-81)
Muncie 4 speed back up lamp switch



p/n 500523
OEM large terminal and double crimping tool (20-8 gauge)




p/n 500649
Multi-crimp tool (20-14 gauge)



p/n 36289 (1978)
p/n 36290 (1979)
p/n 36291 (1980)

Factory assembly manuals
(It's what they used on the assembly line to build your Camaro!)



www.americanautowire.com 856-933-0801

Classic Update Series

1978-80 Camaro

510581


© COPYRIGHT 2004 American Autowire / Factory-Fit
Used with express permission of
American Autowire / Factory-Fit
92970957 instruction sheet rev. 0.0 8/19/2014

Classic Update Series

1978-80 Camaro




www.americanautowire.com 856-933-0801



NOTICE: This schematic drawing is for reference only. Do not use the schematic to install this wiring kit! Use the instruction sheets included in each bag, which includes directions for proper terminations, and specific applications (such as Rally Sport).

510581

© COPYRIGHT 2004 American Autowire / Factory-Fit
Used with express permission of American Autowire / Factory-Fit
92970957 instruction sheet rev. 0.0 8/19/2014



- orange
- lt blue
- tan
- dk green
- yellow
- brown
- lt green



- red
- pink
- brown
- red
- tan
- purple

510581

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

