



1. Plug the 510400 power top harness (purple and gray wires) into the motor connection and onto the switch connection.
2. Plug the bare terminal end of 510400 power jumper harness (red wires) into accessory connector #3 on the dash harness 510190 maintaining color continuity with red wire in that location as shown above .
3. Cut the ring terminal off of the main power wire of your original or reproduction power top switch assembly, and install one of the supplied female terminals onto that wire. Plug this wire into one of the pigtails on the 510400 power jumper harness as shown above. **NOTE:** On a **1964-65** top switch, the main power wire is usually yellow or orange in color, but it will be to only wire on the switch assembly with a ring terminal on it. On a **1966-67** top switch, the main power wire is usually black in color, but it will be to only wire on the witch assembly with a ring terminal on it.
4. Clip off the first section of the enclosed 30 amp circuit breaker, remove the 30 amp fuse from "BAT2" location on the fusebox, and replace it with the 30 amp circuit breaker.



www.americanautowire.com 856-933-0801

