



1. There are 2 dual headlight bucket harnesses (used on all vehicles) and 2 quad headlight extension harnesses (used on the **1958-60** vehicles) included in this kit.

2. All Vehicles:

Install a dual headlight bucket harness by routing the 2-way connector that connects to the dash harness **510652** through the headlight bucket from the inside of the bucket to the outside of the bucket. Note that the grommet on the dual headlight bucket harness has an interference fit to the loom and may move. Be careful to seat the grommet in the bucket without displacing the grommet on the loom. The 3-way connector on the dual headlight bucket harness connects to the low beam headlight; the 2-way T-shaped connector on the dual headlight bucket harness will connect to the quad headlight extension harness for vehicles with quad headlights.

3. Quad Headlight Extension Harness:

If you have a **1958-60** vehicle with quad headlights, you will need to connect the quad headlight extension harness to the dual headlight bucket harness that was just installed in step #2. After connecting the two harnesses together, the other 2-way connector on the quad headlight extension harness will connect to the high beam headlight.



**American
Autowire**

www.americanautowire.com 856-933-0801

