



Plug this connector into the alternator.

This connector is for the low voltage generator light if you are using one.

Plug this connector into the stator terminal on the alternator.

Plug in the brown alternator wire with the white connector from your AAW harness into this connector

