

In this kit you will find the following:

1. Three Firewall Grommets - 2(G) and 1(R), and two Front Core Support Grommets (Z), (as shown on page 2).
 - a. The two G grommets install in the same outboard locations as the original 1 1/4" (hole diameter) Firewall Wiring Grommets. Attach these two grommets to the Fire wall. The LH and RH branches of the Dash Harness (510369) will pass through these grommets to the Engine Compartment.
 - b. The R grommet will install in the same location as the original 1" (hole diameter) Firewall Wiring Grommet. This is located near the upper center part of the Firewall. The Engine Wiring branch of the Dash Harness (510369) will pass through this grommet and route onto the engine.
 - c. The two Z grommets will install in the Front Core Support where the original 1 1/4" (hole diameter) Front Lighting Wiring grommets are located. Route the Front Lighting Wiring from the Dash Harness through these grommets to the lights.
2. Misc. Connectors, Terminals, and Sleeves, (shown on page 2).
 - a. Use these parts to complete the connections from the Dash Harness (510369) to the various components in the Engine Compartment and Passenger Compartment
3. Two Door Jamb Switches.
 - a. To be installed in each Door Jamb, after the Dash Harness wiring is connected to the switches, (see the Installation Instructions 92970307).



www.americanautowire.com 856-933-0801

PART #

























510376

DESCRIPTION:

Parts Kit
1967-72 Ford Truck
Classic Update Series

92970339 Rev 1.0 5/5/2014

In the box below, you will find the legend for the misc. terminals, plastic connector bodies, and the main firewall grommets that will be used to complete your main power, forward lighting, engine, and alternator connections. They are itemized and referred to on this page just as they are on pages 11 and 12 of the Main instruction set (92970307).

- | | | | | | |
|---|---|--|---|---|---|
| A |  | (larger 59 series single female terminal, 6 pcs.) | Q |  | (56 series single female HEI tach conn., 1 pc.) |
| B |  | (smaller 56 series single female terminal, 30 pcs.) | R |  | (small main firewall grommet 1 inch, 1 pc.) |
| C |  | (smaller 56 series double female terminal, 12 pcs.) | S |  | (56 series 4-way female connector, 1 pc.) |
| D |  | (large rubber sleeve, 4 pcs.) | T |  | (56 series 2-way female connector, 4 pcs.) |
| E |  | (56 series single female conn. with lock wedge, 3 pcs.) | U |  | (188 series male bullet terminal, 2 pcs.) |
| F |  | (smaller 58 series single female terminal, 5 pcs.) | V |  | (56 series 2-way male connector, 2 pcs.) |
| G |  | (large main firewall grommet 1-1/4 inch, thick, 2 pcs.) | W |  | (56 series single male terminal, 6 pcs.) |
| H |  | (58 series single female connector for use with terminal F, 1 pc.) | X |  | (Female bullet terminal, 4 pcs.) |
| J |  | (small rubber sleeve, 4 pcs.) | Y |  | (door jamb switch, 2 pcs.) |
| K |  | (small ring terminal for larger gauge wire, 6 pcs.) | Z |  | (large core support grommet 1-1/4 inch, thin, 2 pcs.) |
| L |  | (large ring terminal, 2 pcs.) | | | |
| M |  | (small ring terminal for smaller gauge wire, 6 pcs.) | | | |
| N |  | (56 series single female conn. with notch, 4 pcs.) | | | |
| P |  | (56 series single female HEI power conn., 1 pc.) | | | |