


This switch is design to delivery momentary 12 volts for a starter circuit.

1. Connect one post to a good 12 volt source with a 12 gauge wire. (usually this is the "start" post on the ignition switch).
2. Connect the other post to the starter solenoid.
3. Turn ignition key to the "start" position, and push button. The starter should engage.



American Autowire Systems

American Autowire makes it easy

FACTORY
automotive
wiring **FIT**

150 Heller Pl #17 W
Bellmawr, NJ 08031
856-933-9301

PART #

500151


DESCRIPTION:

**PUSH BUTTON
STARTER SWITCH**

92965223 instruction sheet Rev 2.0 3/16/2001

This switch is design to delivery momentary 12 volts for a starter circuit.

1. Connect one post to a good 12 volt source with a 12 gauge wire. (usually this is the "start" post on the ignition switch).
2. Connect the other post to the starter solenoid.
3. Turn ignition key to the "start" position, and push button. The starter should engage.



American Autowire Systems

American Autowire makes it easy

FACTORY
automotive
wiring **FIT**

150 Heller Pl #17 W
Bellmawr, NJ 08031
856-933-9301

PART #

500151

DESCRIPTION:

**PUSH BUTTON
STARTER SWITCH**

92965223 instruction sheet Rev 2.0 3/16/2001