


Classic Update Series



USE THIS SHEET FOR A
62-65 NOVA



**American
Autowire**

American Autowire
800-482-9473

Classic Update Series



















bag **M**

REAR BODY KIT


510146

92969284 instruction rev 1.0 12/13/2010

USE THIS SHEET FOR A 62-65 NOVA CAR

A		LIGHT BLUE TAN	Third brake light Fuel Tank lead	Connect the main connector to the mating connector on the dash harness 500957 bag G. Route this harness along door sill and into trunk
B				Connect to the third brake lamp, if equipped. From inside the car, install grommet U (larger) into access hole in the rear floor area of the car. Install sender pigtail R onto sending unit underneath the car and pass the wire up through grommet U and into the car. Cut to length and install terminal C and connector L as shown on sheet 1. Route the tan wire in the main connector to the rear of the car so that it will mate with the tan sender wire. Cut the main wire to length and install terminal J and connector H, then plug this wire into the sender pigtail wire assembly as shown on sheet 1.
C				
D		BROWN	Parking lamps	Route this wire to the left side tail light and trim to length. Double this wire with the cut off portion and install terminal D and plug into connector E. Route the loose end through grommet T (smaller) and through to the license plate lamp. Cut to length, and double this wire with the cut off portion, using terminal N, plug into connector H as shown on sheet 1. Route the loose end back through grommet T into the trunk of the car, and over to the right side tail lamp, trim to length, install terminal C and plug into connector E as shown on sheet 1.
E				
F		YELLOW	LH Stop / Tail	Route this wire to the LH tail lamp, cut to length and install terminal C. Plug this wire into connector E from above maintaining color continuity with pigtail A.
G		DK GREEN	RH Stop / Tail	Route this wire to the RH tail lamp, cut to length and install terminal D. Plug this wire into connector E from above maintaining color continuity with pigtail A.
H		LIGHT GREEN	Back up lamp feed	Route this wire to the LH back up lamp, trim to length and install terminal D and connector L.
J				Route the loose end of the lt green wire to the right side back up lamp and install terminal C and connector L. Plug on extensions B (1962-64) or G (1965) to complete the back-up lamp circuits.
L				At the driver's side kick panel area, cut this wire and double it with the cut off portion using terminal D, and plug into connector E maintaining color continuity with the mating connector in the courtesy lamp kit (bag N).
N				If you are using a dome lamp, route the loose end of this wire to the rear pillar area of the trunk, and install terminal J and connector F. Plug into connector F in location shown on sheet 1. (Note: a factory dome lamp harness will also plug into this connector, if you are not replacing the headliner at this time.)
S				Install the loose white wire S (supplied with terminal installed) into the dome lamp. Route this wire to connector F (on white wire) location and trim to length. Install terminal C and connector E, maintaining color continuity with the white wire in connector F.
T				
U		ORANGE	Courtesy Lamp	At the driver's side kick panel area, cut this wire an double it with the cut off portion using terminal D, and plug into connector E maintaining color continuity with the mating connector in the courtesy lamp kit (bag N).
R				If you are using a dome lamp, route the loose end of this wire to the rear pillar area of the trunk, and install terminal J and connector F. Plug into connector F in location shown on sheet 1. (Note: a factory dome lamp harness will also plug into this connector, if you are not replacing the headliner at this time.)
S				Install the loose orange wire S (supplied with terminal installed) into the dome lamp. Route this wire to connector F (on orange wire) location and trim to length. Install terminal C and connector E, maintaining color continuity with the orange wire in connector F.
T				
U				

Classic Update Series



USE THIS SHEET FOR A
66-67 NOVA



**American
Autowire**

American Autowire
800-482-9473













Classic Update Series bag
M

REAR BODY KIT

510146

92969284 instruction rev 1.0 12/13/2010

USE THIS SHEET FOR A 66-67 NOVA CAR

A				Connect the main connector to the mating connector on the dash harness 500957 bag G. Route this harness along door sill and into trunk
	LIGHT BLUE	Third brake light		Connect to the third brake lamp, if equipped.
B		TAN	Fuel Tank lead	From inside the car, install grommet Q into access hole in the rear floor area of the car. Install sender pigtail R onto sending unit underneath the car and pass the wire up through grommet U and into the car. Cut to length and install terminal C and connector L as shown on sheet 3. Route the tan wire in the main connector to the rear of the car so that it will mate with the tan sender wire. Cut the main wire to length and install terminal J and connector H, then plug this wire into the sender pigtail wire assembly as shown on sheet 3.
C				
D				
E		BROWN	Parking lamps	Route this wire to the left side tail light and trim to length. Double this wire with the cut off portion and install terminal D and plug into connector E. Route the loose end to the license plate lamp. Cut to length, and double this wire with the cut off portion, using terminal N, plug into connector H as shown on sheet 3. Route the loose end over to the right side tail lamp, trim to length, install terminal C and plug into connector E as shown on sheet 3.
F		YELLOW LH	Stop / Tail	Route this wire to the LH tail lamp, cut to length and install terminal C. Plug this wire into connector E from above maintaining color continuity with pigtail A.
H		DK GREEN	RH Stop / Tail	Route this wire to the RH tail lamp, cut to length and install terminal D. Plug this wire into connector E from above maintaining color continuity with pigtail A.
	LIGHT GREEN	Back up lamp feed		Route this wire to the LH back up lamp, trim to length and install terminal D and connector L. Route the loose end of the lt green wire to the right side back up lamp and install terminal C and connector L.
J		WHITE	Courtesy ground	At the driver's side kick panel area, cut this wire and double it with the cut off portion using terminal D, and plug into connector E maintaining color continuity with the mating connector in the courtesy lamp kit (bag N).
L				If you are using a dome lamp, route the loose end of this wire to the rear pillar area of the trunk, and install terminal J and connector F. Plug into connector F in location shown on sheet 1. (Note: a factory dome lamp harness will also plug into this connector, if you are not replacing the headliner at this time.) Install the loose white wire S (supplied with terminal installed) into the dome lamp. Route this wire to connector F (on white wire) location and trim to length. Install terminal C and connector E, maintaining color continuity with the white wire in connector F.
N				
Q		ORANGE	Courtesy Lamp	At the driver's side kick panel area, cut this wire and double it with the cut off portion using terminal D, and plug into connector E maintaining color continuity with the mating connector in the courtesy lamp kit (bag N).
R				If you are using a dome lamp, route the loose end of this wire to the rear pillar area of the trunk, and install terminal J and connector F. Plug into connector F in location shown on sheet 1. (Note: a factory dome lamp harness will also plug into this connector, if you are not replacing the headliner at this time.) Install the loose orange wire S (supplied with terminal installed) into the dome lamp. Route this wire to connector F (on orange wire) location and trim to length. Install terminal C and connector E, maintaining color continuity with the orange wire in connector F.
S	