

Connect the main connector to the mating connector on the dash harness **510646** bag G. Route this harness along the doorsill and into the trunk area.

(NOTE: The **1970-72** cars used a non-serviceable tail light bucket assembly. The light sockets were part of those light assemblies and cannot be replaced. **You must either re-use your original light assemblies, or purchase new ones from your favorite parts supplier.** This kit provides the terminals **M** and **N**, and connectors **H** that are necessary to make the connection to your rear light assemblies.)

LIGHT BLUE	Third brake light	Connect to the third brake light, if equipped.
TAN	Fuel signal	Route this wire to the fuel sender and trim to length. Install terminal M and plug into connector G , at right-angle pin grip L install terminal P and plug into connector K , plug connector K into connector G as shown on pages 2-4 .
BROWN	Rear Running Lights	Route this wire to the LH side marker light, trim to length, double this wire with the cut off portion, install terminal R , plug into connector K , then plug connector K into side marker pigtail E as shown on pages 2 & 3 . Route the loose end of this brown wire to the LH tail light bucket area, cut to length, double this wire with the cut off portion, install terminal R and plug into connector J in the location shown on pages 2 & 3 . Route the loose end of this brown wire to the license light area, cut to length, double this wire with the cut off portion, install terminal N and plug into connector G as shown on pages 2 & 3 . Route the loose end of his brown wire to the RH tail light bucket area, cut to length, double this wire with the cut off portion, install terminal R and plug into the other connector J in the location shown on pages 2 & 3 . Route the loose end of this brown wire to the RH side marker light, cut to length, install terminal P , plug into connector K , then plug connector K into side marker pigtail E from above as shown on pages 2 & 3 .

(NOTE: New terminal **U** and connector **K** have been provided for your license light lead in the event that your original lead needs repair.)

YELLOW	LH Stop / Tail	Route this yellow wire to the LH tail light bucket area, cut to length, install terminal P and plug into connector J or terminal M and connector H , in the location shown on pages 2-4 .
DK GREEN	RH Stop / Tail	Route this dk. green wire to the RH tail light bucket area, cut to length, install terminal P and plug into the other connector J or terminal M and connector H , in the location shown on pages 2-4 .
















(NOTE: New terminal **P** and connector **K** have been provided for your Back-up light lead in the event that your original lead needs repair.)

LIGHT GREEN	Back-up light feed	Route this wire to the LH tail light bucket area, cut to length, double this wire with the cut off portion, install terminal N , and plug into connector G in the location shown on pages 2-4 . Route the loose end of this Lt green wire to the RH tail light bucket area, cut to length, install terminal M and plug into the other connector G in the location shown on pages 2-4 .
-------------	--------------------	--


(NOTE: **1970-72** - Plug your tail light bucket assemblies (**not included with this kit**) into the (2) connectors **J** from above to complete your stop/turn, tail, and back-up light connections. New terminals **P** and **R** and connector **J** have been provided for you in the event that your original leads need repair.)

(NOTE: A completed dome light assembly **F** has been provided for you to use if your car is a coupe or sedan. **If you have a convertible, you will need to purchase the "Convertible Rear Armrest Courtesy Light Kit", P/N 510199 separately.**)


WHITE	Courtesy ground	Route this white wire (along with the orange wire below) along the doorsill and back toward the trunk. Cut this wire to length, install terminal M , and plug into connector H in the location shown on pages 2-4 .
ORANGE	Courtesy light Feed	Route this orange wire (along with the white wire above) along the doorsill and back toward the trunk, then up into the "C" pillar or sail panel area. Cut this wire to length, double it with the cut off portion, install terminal N , and plug into the empty cavity of connector H in the location shown on pages 2-4 . Route the remaining portion of this orange wire back to the LH trunk hinge area, cut to length, install terminal P and plug into connector K (NOTE: Your trunk light assembly [Not included with this kit] will plug onto connector K to complete your trunk light connection). Once you have completed connector H , you can plug in your dome or Convertible Rear Armrest Courtesy light Kit to complete those circuits.



www.americanautowire.com 856-933-0801



Classic Update Series




1968 Olds Cutlass

NOTE: The "E" Side Marker Light Jumper Harnesses, on this page, use a #194 bulb (not included with this kit). They may be purchased at any auto parts store.

1968-72
Olds Cutlass
REAR BODY KIT
510650

Classic Update Series

1969 Olds Cutlass




NOTE: The "E" Side Marker Light Jumper Harnesses, on this page, use a #194 bulb (not included with this kit). They may be purchased at any auto parts store.

NOTE: The "C & D" Stop, Turn, Tail Light Jumper Harnesses, on this page, use a #1157 bulb (not included with this kit). They may be purchased at any auto parts store.

1968-72 Olds Cutlass REAR BODY KIT 510650

Classic Update Series

1970-72 Olds Cutlass



1968-72
Olds Cutlass
REAR BODY KIT
510650